



## SC Firmware update

In this documentation you will find information about:

- Process of updating DS/HE/BB series firmware.

The Stage Control Firmware update manual guides you through the process of deleting old and installing the latest available firmware.

- Before starting this procedure download the corresponding **ffi** factory file (DS20, DS50, HE50, DS450 or BB35) from the Stage Accompany website (software) and save it in a map to load it later.
- Download the latest release of Stage Control software by clicking this link: [Stage Accompany](#) and install it.
- Connect the DS20, DS50, DS450, HE50 or BB35 to the ethernet connection and start up the Stage Control program. Open the connected amplifier by clicking the green arrow.
- **Please note that all existing presets will be deleted by updating the firmware . Store your personal presets on a local drive first to reload them later, all standard presets will be loaded after loading the factory settings!**
- Go to <Hardware> <Enter Password> and unlock your amplifier by using the password: Ad\_min
- Go to <Hardware> <Firmware update> <OK> <OK> and the latest firmware will be installed.
- Press <OK> when finished.
- Go to <Hardware> <Enter Password> and unlock your amplifier by using the password: Ad\_min
- Go to <File> <Load Factory Settings> <OK>, select the right **ffi** file dedicated to the type of amplifier type and open it. Wait for the entire system is synced and the all amplifier settings will be upgraded.
- Press <OK> when finished.
- Close the complete Stage Control application and restart it.
- After this your personal presets could be loaded and stored to the unit.